

SPARE PARTS LIST

PAGE 1

MODEL NO. BUC122

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	158472-4	KNOB 60 COMPLETE	1	
002	267004-7	FLAT WASHER 6	1	
003	158471-6	SPROCKET COVER COMPLETE	1	
004	961014-3	STOP RING E-8	1	
005	221527-9	SPROCKET 9	1	
006	267732-4	LOCK WASHER 12	1	
007	232238-1	LEAF SPRING	1	
008	265995-6	TAPPING SCREW 4X18	1	
009	265995-6	TAPPING SCREW 4X18	3	
010	450213-7	BEARING HOUSING	1	
011	323806-2	SPINDLE	1	
012	211051-0	BALL BEARING 609LLB	1	
013	226673-3	HELICAL GEAR 50	1	
014	450436-7	CAM	1	
015	210033-9	BALL BEARING 696ZZ	1	
016	450435-9	CRANK	1	
017	213993-4	O-RING 1.5	1	
018	158571-2	OIL PUMP COMPLETE	1	
019	421615-4	CONNECTOR	1	
020	158810-0	TANK CAP COMPLETE	1	
022	158634-4	OIL TANK COMPLETE	1	
023	*****	*****	***	*****
024	231470-4	COMPRESSION SPRING 6	1	
025	416178-3	LOCK-OFF BUTTON	1	
026	651956-6	SWITCH TG72BD	1	
027	450212-9	SWITCH LEVER	1	
028	*****	*****	***	*****
029	257264-9	RING 30	1	
030	265995-6	TAPPING SCREW 4X18	4	
031	619225-1	ARMATURE	1	
032	638138-7	YOKE UNIT	1	
033	638608-6	ENDBELL COMPLETE	1	
034	188468-1	MOTOR HOUSING SET INC. 36	1	
035	864638-3	BUC122 NAME PLATE	1	
036	188468-1	MOTOR HOUSING SET INC. 34	1	
037	266050-7	TAPPING SCREW 4X30	4	
038	191971-3	CARBON BRUSH CB-430	1	
039	643954-4	BRUSH HOLDER CAP	2	
040	*****	*****	***	*****
041	265995-6	TAPPING SCREW 4X18	6	
042	158620-5	FRONT HAND GUARD COMPLETE	1	
043	266050-7	TAPPING SCREW 4X30	2	
044	450217-9	FRONT HANDLE	1	
045	266050-7	TAPPING SCREW 4X30	1	
046	265995-6	TAPPING SCREW 4X18	2	
047	259041-5	PUSH NUT 8	1	
048	443125-1	FILTER	1	
A01	158476-6	GUIDE BAR COMPLETE	1	
A02	416311-7	GUIDE BAR CASE	1	
A03	182229-1	OIL SUPPLY 100CC	1	
A04	744003-1	FILE 4	1	
A05	791284-8	CHAIN BLADE	1	
A06	824820-6	PLASTIC CARRYING CASE	1	
A07	808472-1	BUC122ZK PLASTIC CASE LABEL	1	
E01	620098-7	CONTROLLER	1	

SERVICE DRAWING

PAGE 1

MODEL NO. BUC122

